The Wayback Machine - https://web.archive.org/web/19980204112345/http://www.nflex.com:80/faq-p2.html

よくある質問

Pokewan

Q.01 My dog is still missing...
(Only the doghouse and chains remain)

A.01 Since he has run away from home, please press the reset button and start raising him from the beginning.

Q.02 The communication button is too hard to press.

A.02 It is shaped to look like a dog's paw and does not affect the gameplay.

Q.03 My dog is still tired...

A.03 It will return to normal over time.

Q.04 What will the ending be?

A.04 One of them is running away from home, but there are several others. Please look forward to seeing the ending.

Q.05 What does "Highest Record M" mean?

A.05 The distance the Frisbee flew.

Q.06 Even when I'm in a request pose, the ringtone sometimes rings and sometimes doesn't...

A.06 It may or may not be called depending on the time and situation
(for example, depending on the degree of dirt).

Q.07 Does your dog's demanding pose last forever?

A.07 It will gradually disappear over time.

Q.08 Will the runaway return?

A.08 Running away from home is an ending, so there is no going back.

Q.09 My dog is getting fat and won't go away.

A.09 Take them for walks often and try not to feed them too much.

Q.10 The dog is smoking a cigarette.

A.10 He has become delinquent, so please play with him often.

Q.11 The dog is still in the house, looking around wildly.

A.11 He has autism so please don't scold him and play with him.

Q.12 My dog has grown so big that the buttons don't work.

A.12 The ending will be in September. There are many other endings, so please start over again.

Q.13 How do you choose the food for your puppy (Hone Dog Food, Inu Manma)?

A.13 The A button is the bone, the B button is the dog food, and the C button is the dog.

Q.14 My dog is still tired...

A.14 It will return to normal over time.

Q.15 The dog can't learn tricks.

A.15 As you do it over and over, your dog will gradually be able to do tricks. When it does a trick, give it a pat and praise it.

Q.16 How long will it take to reach the ending?

A.16 The endings will be in January, March, and September.

Q.17 Can a dog die?

A.17 They may run away from home, but they will not die.

Q.18 Why do you run away from home?

A.18 If you don't pay enough attention to your dog, he will sulk and run away. On the other hand, if you pamper him too much and feed him until he is full, wash him even though he is clean, or scold him when there is no need to scold him, he will run away.

Q.19 The dog came into the house with only its rear end exposed and trembling.

A.19 He is on the verge of becoming autistic, so please play with him and don't scold him.

Q.20 The reset button didn't work.

A.20 The reset button is a black button located at the bottom of the back of the device. When pressing the reset button, use a thin rod or similar object. However, when pressing it with a mechanical pencil or pencil, be careful not to get the lead stuck in the tip, as this may cause a malfunction.

Q.21 How do you clean up poop?

A.21 When your dog is a baby, use the cleaning icon to remove its poop. From the puppy stage, use the training icon to train it so that it is less likely to get dirty. If you train your dog too much, it will be more likely to develop autism, so be sure to use the cleaning icon as well.

Q.22 The dog ran away from the kennel and never came back.

A.22 You have run away from home. This is the ending, so you will not come back. Press the reset button and start over.

Q.23 The dog is wearing a hat and playing with a frisbee and ball, and the screen remains motionless.

A.23 One of the endings is a clown. Press the reset button, or press buttons A and C simultaneously on the dog screen to start over.

Q.24 I'm not good at catching the ball.

A.24 Press the confirm button the moment the ball lands.

Q.25 Only three changes?

A.25 It is shown three times, from when the dog is a baby, a young dog, and a puppy, and the ending changes at the end.

Q.26 The crab came out.

A.26 There is no particular meaning behind the dog playing with the crab.

Q.27 He became a bad dog.

A.27 Playing with your child often will help them to correct bad habits and make them less likely to develop them again.

Q.28 Is there a list of endings?

A.28 There is no list of endings, but there are about six different endings, such as running away from home or getting married. Aim for a wonderful ending. If you have come across an ending like this, please let us know by email. We will post it in the FAQ.

Q.29 My body is "clean" but I still want to be washed. Why?

A.29 Even if the area is clean, your dog may ask to be washed, so please wash him.

Q.30 How can I keep my dog from escaping when he's on a leash?

A.30 Too bad! The moment your dog is chained up, it's already a "runaway." You have no choice but to let it run away. Let's try again.

Q.31 Icons like "teaching tricks" when the dog was a puppy have disappeared.

A.31 Your dog is overweight. If your dog becomes too fat, the icon will disappear because your dog doesn't want to do anything. Feed them less and take them for more walks.

In addition to any questions, please feel free to send any comments or thoughts you may have about Pokewan to the address below.

info-nf@nflex.com

Return to product information